

## PERGAQUICK C100 Cobalt accelerators / Curing

## Description

Cobaltoctoate

10%, Liquid

PERGAQUICK C100 is used as an accelerator for curing of unsaturated polyester resins at ambient temperature in combination with Ketone peroxides

$$\begin{bmatrix} 0 \\ || \\ 0^{-C} \\ CH \\ CH \\ CH^{-} \\ CH^{-}$$

CAS No.:

136-52-7

Technical data	Appearance: Active substance assay: Density at 20°C:	dark liquid appx. 10% 1.03 g/cm³
Storage	Maximum storage temperature (Ts max): Minimum storage temperature (Ts min): Storage stability as from date of delivery:	30°C 5°C 6 months

Keep packaging tightly closed in a well ventilated place at indicated storage temperature.

Hazardous reactions

Might react violently with organic peroxides. It is therefore not allowed to store or transport the product together with peroxides. NEVER BRING AN ACCELERATOR INTO DIRECT CONTACT WITH PEROXIDES!





## **PERGAQUICK C100**

**Cobalt accelerators / Curing** 

## Application

The curing of unsaturated polyester resins at ambient temperatures can in general not be performed by an organic peroxide alone. The radical formation which is necessary - to start the polymerisation reaction - is too slow at ambient temperatures with most generally applied organic peroxides.

To speed up the radical formation in a controllable way, organic peroxides must therefore be used in combination with a so called accelerator. For ketone peroxides - like Methylethylketone peroxides, cyclohexanone peroxides and acetylacetone peroxide - a cobalt accelerator must be used.

For this purpose the following formulations of cobalt octoate are available: PERGAQUICK C100 10% cobalt PERGAQUICK C60 X 6% cobalt in TXIB PERGAQUICK C12 X 1% cobalt in TXIB

The reactivity of the various cobalt accelerator formulations is directly correlated with the cobalt content. The use of a lower concentrated version increases the dosage accuracy. However, when the dosage level of e.g. PERGAQUICK C12 X must be higher than appox. 3% to achieve the required cure performance, it is advised to use a higher concentrated cobalt accelerator like e.g. 0,5% PERGAQUICK C60 X.

Apart from the choice of the ketone peroxide, the cure characteristics of an unsaturated polyester resin/ ketone peroxide mixture can be influenced very effectively by the dosage level of the cobalt accelerator. For this purpose, the dosage level of the cobalt accelerator expressed as PERGAQUICK C100 (10% Co) can be varied from e.g. 0,025 phr up to approx. 0,6 phr.

When the right peroxide has been chosen and still the required gel time and cure characteristics can not be obtained with the cobalt accelerator alone, it is possible to increase the reactivity of the cobalt accelerator by the extra addition of a promotor like PERGAQUICK A200 (DMA).

This adaptation of the accelerator system may be necessary when:

- a very short gel time and/or fast cure is required, e.g. for RTM or manufacture or polymer concrete
- highly inhibited and/or low reactive resins must be cured e.g. bisphenol A/fumarate or vinylesters

The cure system ketone peroxide/cobalt accelerator can be characterized by:

- the relatively low colour, related to cobalt dosage, of the cured moulding

- a very good UV light stability of the moulded parts

- the long pot life of the cobalt accelerator in the polyester resin

Disadvantages can be that the cure system is more sensitive to moisture, pigments and fillers than the cure system Dibenzoyl peroxide / Amine accelerator.

Depending on application area and working conditions, the following accelerator dosage levels are recommended: PERGAQUICK C100: 0,025 to 0,6 phr

30kg container 200kg steel drum

Major decomposition products In case of fire, Cobalt oxides and carbonmonoxide may be formed

Please refer to the material safety data sheet (MSDS) for information concerning safe storage, use and handling Safety and handling of PERGAQUICK C100. This information should be thoroughly reviewed prior to acceptance of this product. The MSDS is available for downloading at www.pergan.com or through contacting Pergan directly.

The information presented herein is true and accurate and to the best of our knowledge, but without any guarantee. Since the conditions of use are beyond our control we disclaim any liability, including for patent infringement, incurred in connection with the use of these products, data or suggestions.



Packaging

Schlavenhorst 71 D-46395 Bocholt Germany

Phone: +49 (0)2871 / 99 02-0 Fax: +49 (0)2871 / 99 02-50 www.pergan.com